

# Doorbell

## Quick Install Guide

### Introduction:

The BOSMA doorbell is an accessory sensor to the BOSMA X1 home security camera. It primarily serves as a simple doorbell at the front door. When it is pressed, it notifies the camera which plays a doorbell ringing sound and sends a notification to your phone.

Alternatively, it could also be used as an emergency button for those that may need immediate attention at any time, e.g. an elderly person at home.




Fig.1

### Installation Guide

#### 1. Pair the doorbell with a BOSMA X1 camera

- Open the BOSMA app, make sure that a BOSMA X1 camera has been added to your account

- Tap “+” button at the top-right corner, and select “Doorbell”
- If you have more than one BOSMA X1 camera, select the one you want the doorbell to be paired with
- Long-press the doorbell button to pair with the camera



Fig.2

## 2. Select installation location

You may install the doorbell on the front door. The sensor uses simple adhesive to stick to a surface. Please install the sensor on a relatively flat and smooth surface

Peel off the adhesive backing, then stick the doorbell to the surface. See figures below.



Fig.3

## Specifications

Model: DR0001

Range (open area): 300ft

Radio Frequency: 915MHZ

Voltage: DC 3.0V

Amperage: Idle  $\leq$  600nA; Working  $\leq$  25mA

Working Temperature: 14 °F ~ 122 °F

Dimensions: 40 \* 80 \* 10.5mm  
Color: White